



Hazard Warning Kit SFB300

Hazard Warning Kit SFB300

COLOUR	WIRING
Purple	Live Feed
Black	Earth
Green	Left Hand Indicators
Green/White	Right Hand Indicators
Green/Purple	Follow instructions below
Green/Purple	Follow instructions below

Find the live feed to your existing flasher unit, cut that wire, then connect a Green/Purple to one end of the wire you have cut and Green/Purple to the other. (The wires from this switch are approximately 500mm long. Depending on the layout of your car you may need to extend some of the wires to reach the connection points listed above). Works on both positive and negative earth vehicles.